



# MAX-AMP MOBILE

5 BAND WIRELESS 4G/LTE CELLULAR AMPLIFIER

## QUICK START GUIDE

### MAX-AMP MOBILE 5 Band Wireless 4G/LTE Cellular Amplifier

---

External mag mount antenna-base, mast, 12 ft. Cable

---

Internal Low Profile Antenna with 10ft. Cable

---

Mini USB power adapter with 4 ft. Cable

---



MAGNET MOUNT  
ANTENNA MAST



MINI USB  
POWER ADAPTER



FRONT AREA  
PATCH ANTENNA



MAGNETIC MOUNT  
ANTENNA BASE

1) Remove all package contents.

2) Select location on the top of your vehicle towards the rear, to place the magnetic mount antenna base ensuring that the antenna cable can reach from the antenna to the **MAX-AMP MOBILE** 5 Band Wireless 4G/LTE Cellular Amplifier.

3) The magnetic mount antenna Base must be placed on at least 8" x 8" ferrous metal surface (piece of metal that the magnetic base adheres to).

4) Hand tighten the magnetic mount antenna mast to the magnetic mount antenna base.

5) Run the magnetic mount antenna CABLE to the **MAX-AMP MOBILE** 5 Band Wireless 4G/LTE Cellular Amplifier. Hand-tighten the magnetic mount cable to the amplifier connector labeled EXT-ANT.

6) Remove the adhesive protective cover on the back of the Internal Patch Antenna. Firmly press the antenna to the firewall facing between the gas and brake pedals with label facing the user.

7) Run the cable from the Internal Patch Antenna to your **MAX-AMP MOBILE** amplifier. Hand-tighten the TNC cable connector at the end of the cable to the connector on your amplifier labeled INT-ANT.

8) Insert the Mini USB Power Adapter into the PWR receptacle on your **MAX-AMP MOBILE** 5 Band Wireless 4G/LTE cellular amplifier. Insert the Power Adapter into the vehicle's power source.

9) The green LED light indicates your **MAX-AMP MOBILE** 5 Band Wireless 4G/LTE Cellular Amplifier has power and is operational. If the red fault light illuminates your antennas are likely incorrectly placed. Immediately unplug the Mini USB power adapter and increase the separation between your Internal and external

antennas. Then reconnect the Mini USB power adapter into your vehicles power source push on the reset switch. You should now have the green LED light indicating your amplifier has power and is operating properly.