



MAX-AMP RV (KIT)

5 BAND WIRELESS 4G/LTE CELLULAR AMPLIFIER

QUICK START GUIDE



KIT INCLUDES:

MAX-AMP MOBILE 5 Band Wireless **4G/LTE** cellular amplifier

Ceiling Antenna with 10 ft. cable

External Antenna with 10 ft. cable

15 ft. cable extension

Mini USB Power Adapter with 4 ft. cable



1 Remove all package contents.

2 Please note: antennas must have a horizontal separation of a minimum of twelve (12) ft. Do not extend cable which will cause reduced performance. Do not use any staples or other items that can puncture thru the cable.

3 Select a location on top of your RV ensuring the external omni directional antenna can reach your cellular amplifier and the antenna has a minimum of 180* line of sight with a minimum of ten (10 inches) above any obstructions.

4 Run the external omni directional antenna cable to the MAX-AMP MOBILE RV 5 Band Wireless **4G/LTE** cellular amplifier.

5 Affix the low profile ceiling antenna securely to the ceiling pointing down thus ensuring that the cable from the antenna can reach the amplifier.

6 Run the cable from the antenna to amplifier. Hand tighten the low profile ceiling antenna cable to the cellular amplifier at the connector labeled INT-ANT being careful to not over tighten as doing so may damage the device thus voiding your warranty.

7 Plug the Mini USB Power Adapter in the MAX-AMP MOBILE 5 Band Wireless **4G/LTE** cellular amplifier at the spot labeled "PWR". Insert into your RV's power source and push the on/off switch on the amplifier. The green LED light indicates your cellular amplifier has power and is operational.

8 If you have a RED fault indicator light illuminated on your MAX-AMP MOBILE 5 Band Wireless **4G/LTE** cellular amplifier, your antenna are not located properly Unplug your power supply cable from your amplifier immediately, increase the separation between the external and internal antennas.

9 Reconnect the power supply cable into your RV power source and push the power on/off switch on amplifier. The green LED light indicates your MAX-AMP MOBILE 5 Band Wireless 4G/LTE cellular amplifier has power.



THIS IS A CONSUMER DEVICE

BEFORE USE, you **MUST REGISTER THIS DEVICE** with your wireless provider and have your provider's consent. Most wireless providers consent to the use of signal boosters. Some providers may not consent to the use of this device on their network. If you are unsure, contact your provider.

You **MUST** operate this device with approved antennas and cables as specified by the manufacturer. Antenna **MUST** be installed at least 20cm (8 inches) from any person.

You **MUST** cease operating this device immediately if requested by the FCC or a licensed wireless service provider

WARNING: E911 location information may not be provided or may be inaccurate for calls served by using this device. You are cautioned that changes or modifications not expressly approved by the FCC will void your authority to operate the equipment.

No exterior antenna can be used with this amplifier that has a gain of more than 3 dBi. No external antenna can be located within thirty nine (39") inches of any person.

No Interior antenna can be used with this amplifier that has a gain of more than 3 dBi. No internal antenna can be located within eight (8") inches of any person.

Do not plug the wireless amplifier into any power supply until all antennas are connected to the amplifier.

The use of any power supply other than the one supplied by Maximum Signal LLC may damage your amplifier and will void your warranty.

Verify the power source you have chosen can support this amplifier.

Select a location to install this amplifier, making sure there is adequate ventilation and no moisture present.